



1 Simply drill a hole with the diameter of the of the cable tie into the mounting wall and thread the cable tie through.



Wrap the cable tie around the bundle, hose, etc. and guide the end of the tie back through the hole in the locking head and pull tight.



3 Finished. The locking head serves as an attaching part.

Bore hole Ø		Locking head	Dimensions Bundling			Art. No. black	Pack Qty.
min.	max.	height	width	length	Ø		,
mm	mm	mm	mm	mm	mm		
2.5	3.8	3.2	2.4	140	1.6 – 32	0502 311 0	
3.8	5.3	3.7	3.4	206	1.6 – 50	0502 321 0	
5.1	6.4	4.2	4.6	172	1.6 – 45	0502 331 0	100
5.1	6.4	4.2	4.6	279	1.6 – 76	0502 341 0 *	
8.0	10.2	6.4	7.6	376	1.6 – 102	0502 351 0 **	

Special Cable Ties for Single-Hole Installation

These cable ties allow economical single-hole installation:

 Without attaching parts, screws, adhesive, etc.

In contrast to our standard cable ties with molded tie head – which requires a 90° insertion angle – these cable ties have a movable locking head. This allows parallel insertion of the end of the cable tie and results in correct seating

- UV-resistant.
- Heat-stabilized.
- Temperature stability from −40°C to +85°C.
- Material: Polyamide 6.6.
- Halogen and silicone free.
 DC Orig. No. 001 997 8390.
 DC Orig. No. 001 997 8490.
- UL certified.

Areas of Application

- Automobile manufacturing, electrical
- Automotive workshops