

## Special Cable Ties for Daimler Benz



| Bundling range<br>mm | Bore hole<br>mm | Attachment<br>Thickness<br>mm | Length<br>mm | OE = No.                               | Art. No.           | Pack<br>Qty. |
|----------------------|-----------------|-------------------------------|--------------|----------------------------------------|--------------------|--------------|
| 10 – 100             | –               | –                             | 370          | DB 001 997 84 90                       | <b>0502 351 0</b>  | 100          |
| 2 – 80               | –               | –                             | 280          | DB 001 997 83 90                       | <b>0502 341 0</b>  | 100          |
| 5 – 70               | –               | –                             | 225          | DB 001 997 43 90                       | <b>0500 125 28</b> | 100          |
| 12 – 40              | 7.5 – 8.0       | 0.6 – 2.5                     | 160          | DB 114 997 05 90 /<br>DB 114 997 02 90 | <b>0500 124 63</b> | 50           |
| 12 – 28              | 7.5 – 8.0       | 0.6 – 2.5                     | 120          | DB 001 997 42 90                       | <b>0500 124 65</b> | 50           |